

MRSN

series
Sub Job Navigation





- Guide the connector to the working position and insert the wire in the correct position and order
- Check by circuit inspection to see if the operating wire is installed correctly
- Simplified wiring inspection: Connection from jig pin to IO board



► Media for this

MRSN Sub Job Navigation



Technical Data

| ITEM | MRSN |
|-------------------------------|--|
| OPERATING SYSTEM | Microsoft Windows 10 |
| OPERATING LANGUAGE | Korean, English, Chinese, Japanese, Spanish, etc. |
| SPEECH | Korean, English, Chinese, Japanese, Spanish, etc. |
| POWER | A.C 100~240V 50/60Hz |
| SIZE | MRSN : 320(W)x350(D)x210(H) mm JIG Table : Customized |
| SIZE OF INSERTION GUIDE LCD | 7" LCD |
| NUMBER OF INSERTION GUIDE LCD | Max. 24 |
| COMMUNICATION PORT | USB, LAN, RS232C |
| etc. | Terminal Locking Check Built in O/S Recovery System |

Options

- Communicste MES System
- JIG LED Guide System
- JIG Table

Headquarters

#1313, 184, Gasan digital 2-ro, Geumcheon-gu, Seoul 08501, Republic of Korea

China Branch

No. 1-2, Tianning Road, Caomiaozi Town, Lingang Economic and Technological Development Zone, Weihai, Shandong 264211, China
(山东省威海临港经济技术开发区草庙子镇天宁路1-2号)

Vietnam Branch

Lot CN7-3, Yen Phong II-C Industrial Park, Cho Town, Yen Phong District, Bac Ninh Province 16206, Vietnam

